



Pins Do Not Release From Turret Properly

Check restricted drop interlock adjustment

Is the left hand blocking finger down

Check the full deck-moving deck interlock adjustment

Is the right hand blocking finger down

Check interlock probe adjustment

Blocking fingers are both up, but interlock probe will not go under them

Adjust turret wires

Is there a pin jammed between a turret wire and the spoons?

Carefully adjust the portion of the pin release lever that the 5 pin contacts to an upward position inside the chute

The 5 pin has gone into the deck with releasing the spider

Click here to Email KMK Experts